

Functions

The link to the lighting system is provided by an OPC server which provides a soft link from the OPC client to the OPC server in Helvar Designer. For the interaction to occur between the two systems the OPC client must conform to Data Access V3 to which the server is designed as specified by the governing body.

The OPC client software provides a visualisation of the extracted information and can issue any control commands to the system. The display configuration and the information that is shown would be determined by the end user.

Available commands & queries

Scene recall and scene recall CL (with constant light) - write only

Show last scene in block selected - read only

Device missing status - read only

Device default name - read only

Device output level - read and write (where supported by device)



Device supply frequency and voltage - read only (where supported by device)

Device temperature and load current - read only (where supported by device)

Designer software version, online & live connection status (read only).

Heartbeat or connection indicator (read only).

Control Flow



Contact your local Helvar representative or visit us online at www.helvar.com

Due to a policy of continuous improvement, Helvar reserve the right to alter specifications without notice at any time.